





## STAIR NOSING GEN-MP-5532

1. If your stairs are made in concrete, prepare the surface of the concrete as smooth as possible, make it free from dust and dirt, round-up sharp edges.



2. After cutting the stair nosing at desired length (the length of the stair), mark and drill holes then insert dowels and tighten with screws. The stair nosings come pre-drilled (one hole at every 45 cm).



**Important :** If your stairs are made in ceramic, marble, granite, stone, they risk to be broken at the time of drilling. In such cases, we recommend you not to fix them with screws but stick with good quality silicone.

3. Cut the anti-slip tape at desired length and stick it. The anti-slip tape is self-adhesive, you do not need to use any glue.

