



VERMONT PLANK FLOORING  
*Floors for living*

[www.vermontplankflooring.com](http://www.vermontplankflooring.com)

+1 (866) 326-2373

112 Hardwood Way.  
Brattleboro, Vermont 05301

# Acclimating your Vermont Plank Floor

1. Establish living conditions at the job site. Air conditioning and/or heating running for at least 5 days, windows & doors installed, all wet construction elements completely dried, for an ideal environment of 60-80° F at 35-50% relative humidity.
2. Ensure the moisture content of your subfloor is tested at multiple locations. We recommend 40 tests per 1000ft.
3. Your hardwood floor will arrive with approximately 7% moisture content. Your subfloor should measure within 3-4 % of the finished flooring.
4. To acclimate effectively, unpack the planks and stack to allow air circulation on all sides.
5. Your flooring is sufficiently acclimated when its moisture content is within 2% of the subfloor.
6. If the moisture content of the new planks and subfloor are within 2% upon arrival, we recommend 48 hours of acclimation before attempting to install.
7. Please be sure to discuss the acclimation process with your installer. This is only intended as a general guide as every installation is unique. Follow NWFA guidelines and the recommendations of your installer.