



# OLD & NEW MODELS CROSS REFERENCE AND PERFORMANCE FOR TYPE L PUMPS

OLD TYPE L SIZE DESIGNATION	OLD TYPE J SIZE ** DESIGNATION	PERFORMANCE * (Where specifies use curve of a new model, this means hydraulic performance is unchanged between old and new)
1"BD 1"BH	IJ-103 IJ-104	Use curve of 1070-5. Use curve of 1070-1.
1 1/4"JE 1 1/4"JB 1 1/4"JS 1 1/4"JW	IJ-143 IJ-141 IJ-147 IJ-146	Old curve T3528B. Use 1250-1 as a replacement. Old curve T3528B. Use 1250-1 or 1250-5 as a replacement. Old curve T3528B. Use 1250-5 as a replacement. Use curve of 1250-5 (1750 rpm)***
1 1/4"JK 1 1/4"JH 1 1/4"BD 1 1/4"MD	IJ-146 IJ-145 IJ-183 IJ-193	Use curve of 1250-5 (3500 rpm)*** Use curve of 1250-1*** Use curve of 1270-5. Use old 1 1/4"MD curve. For replacement, use 1595-5 (1 1/2").
1 1/2"JT 1 1/2"JD 1 1/2"JK 1 1/2"BD	IJ-242 IJ-242 IJ-246 IJ-283	Use curve of 1550-5 (1750 rpm)*** Use curve of 1550-5 (3500 rpm)*** Use curve of 1550-1. Use curve of 1570-1.
1 1/2"BH 1 1/2"M (MC) 1 1/2"C (CC) 1 1/2"DD	IJ-284 IJ-292 IJ-302 IJ-323	Use old 1 1/2"BH curve. For replacement, use 1570-1. Use old 1 1/2"M curve. For replacement, use 1595-5 on 1750 or 1595-1 on 3500 rpm. Use old 1 1/2"C curve. For replacement, consult new curves. Use old 1 1/2"DD curve. For replacement, consult new curves.
2"AD 2"BD 2"MC 2"C (CC) 2"DD	IJ-343 IJ-363 IJ-372 IJ-382 IJ-403	Use curve of 2050-1. Use curve of 2070-5. Use old 2"MC curve. For replacement, use 2095-1. Use old 2"C curve. For replacement, 3500 rpm, use 2095-1. Use old 2"DD curve. For replacement, consult new curves.
2 1/2"AD 2 1/2"MK 2 1/2"HD	IJ-423 IJ-456 IJ-459	Use curve of 2570-5. Use old 2 1/2"MK curve. For replacement, use 2595-1. Use curve of 2595-1.
3"AH 3"AR 3"MB	IJ-504 IJ-508 IJ-521	Use old 3"AH curve. For replacement, use 3070-5. Use curve of 3070-5. Use old 3"MB curve. For replacement, use 3095-1.
3"CC 3"CH 3"D (DD)	IJ-542 - -	Use curve of 3012-5. Use curve of 3012-1. Use curve of 3015-5.
4"A (AH) 4"MA 4"B (BB) 4"CD	IJ-584 IJ-595 - -	Use old 4"A curve. For replacement, use 4070-5. Use curve of 4095-5. Use curve of 4012-5. Use curve of 4015-5.
5"BD 5"C (CC) 6"A (AD) 8"AD 10"BH	- - - - -	Use curve of 5012-1. Use curve of 5015-5. Use curve of 6012-1. Use curve of 8012-1. Use curve of 10017.

\*Older models did not have impellers with the slight extra diameter; example, 1"BD, 2"BD, 3"AR etc., had impellers with max. dia. of 7", equivalent new models have max. dia. 7-3/32".

\*\*Second group of numbers on series J indicated motor size, phase, voltage; consult nameplate of motor on the pump, or refer to the Company.

\*\*\*While these impellers are hydraulically identical between old and new models, the standard impeller trim recommended for various motor sizes have undergone changes.

## PACIFIC PUMPING COMPANY

Manufacturers of Pumps since 1987

Main office and factory

9201 San Leandro Street, Oakland, CA

Mailing Address — P.O. Box 12924, Oakland, CA 94604

PACO Sales Representatives & Distributors in all  
principal cities throughout the U.S. and the free world.

MEMBER

