



LEGEND

- CONDUCTORS CONNECTED
- - CONDUCTORS NOT CONNECTED
- ← CONDUCTOR INDICATING LOAD DIRECTION
- ⎓ CURRENT TRANSFORMER

Warning:

- Only qualified electrical personnel should install this equipment.
- Before performing installation or maintenance, disconnect all sources of electric power.
- Use appropriate personal protective equipment (PPE) and follow safe electrical work practices.

Find diagrams for more configurations at wattwatchers.com.au/support

Installation Notes:

- Auditor is DIN-rail mounted and requires 35mm wide space.
- Current transformer installation – For load monitoring, K is towards the grid, arrow is towards the load.
- Current transformers must be suitably secured in position.
- All wiring shall be tidy and secured in accordance with the wiring rules in your jurisdiction.
- An existing or new protective device can be used depending on the regulations in your jurisdiction.
- Follow the rules in your jurisdiction for the use of RCD protection.
- For more information, refer to the quick start guide and wattwatchers.com.au/support

Issue	Description	Drawn	Approved	Date
1				03/19
2				
3				
4				
5				



T 2 9 WATTWAT	
A M A T V	A T T T T A W
I T A T M	T A W T A B A T
A T A W	T W T W
A M	V W T T W T
	WATTWAT

Client Details	
Drawn By	KS
Date	03/19
Approved By	JC
Date	03/19

Project title	
CONNECTION DIAGRAMS	

Drawing title	
A6W MONITORING SIX 1-PHASE LOADS CONNECTION DIAGRAM	

Project Code	
20180153	
Drawing No	
WW018037	

Status	FINAL
Revision	A
Scale	NTS