



**LEGEND**

- CONDUCTORS CONNECTED
- CONDUCTORS NOT CONNECTED
- CONDUCTOR INDICATING LOAD DIRECTION
- ROGOWSKI COIL CURRENT TRANSFORMER

- Only qualified electrical personnel should install this equipment.
- Before performing installation or maintenance, disconnect all sources of electric power.
- Use appropriate personal protective equipment (PPE) and follow safe electrical work practices.

- Installation Notes:**
- 1) Auditor is DIN-rail mounted and requires 35mm wide space.
  - 2) Current transformer installation – For load monitoring, K is towards the grid, arrow is towards the load.
  - 3) Connect the R-coil shields to the respective coil terminals marked 1-, 2-, 3-
  - 4) Current transformers must be suitably secured in position.
  - 5) All wiring shall be tidy and secured in accordance with the wiring rules in your jurisdiction.
  - 6) An existing or new protective device can be used depending on the regulations in your jurisdiction.
  - 7) Follow the rules in your jurisdiction for the use of RCD protection.
  - 8) For more information, refer to the quick start guide and [wattwatchers.com.au/support](http://wattwatchers.com.au/support)

Place rogowski coil connected to...	On cables connected to...
Terminals 1+ and 1-	A-Phase
Terminals 2+ and 2-	B-Phase
Terminals 3+ and 3-	C-Phase

Find diagrams for more configurations at [wattwatchers.com.au/support](http://wattwatchers.com.au/support)