



---

## Technical Bulletin

**Issue Date:** May 19<sup>th</sup>, 2021  
**Issued By:** FiberTite Technical Services  
**Re:** [FiberTite Induction Welding Equipment](#)

---

**Notice:** In March 2020, FiberTite Roof Systems announced exclusively utilizing the SFS isoweld® induction weld attachment system.

To assist in the proper installation of a FiberTite-IW Roof System, FiberTite Roof Systems is pleased to provide the FiberTite Induction Welding Installation Guide:

[FTR-IW Induction Welding Installation Guide](#) (link)

The Guide is also located on the FiberTite website – [www.FiberTite.com](http://www.FiberTite.com) > Document Library > Product Data Sheets > Fasteners & Stress Plates.

Please Note - Seaman Corporation's warrantable requirements for an Induction Weld Attached Roofing System include the exclusive use of FiberTite Induction Weld Plates (FTR-IW Plates) induction welded to FiberTite Membrane utilizing the SFS isoweld® Induction Welding System, which include the isoweld® 3000 Stand-up Tool / Hand-held Inductor / isoweld® Backpack.

With this clarification, projects utilizing alternate induction welding plates and / or equipment fail to meet Seaman Corporation's warrantable requirements.

For Technical Assistance and Roof Design Needs,  
contact FiberTite Technical Services at 800-927-8578.