

MAXITROL®

myfire® – Initial App Setup

Download on the
App Store

ANDROID APP ON
Google Play



DOWNLOAD THE MYFIRE APP

To download the myfire app search for “myfire” at the Apple App Store or at Google Play.



For more information go to:
www.myfireapp.com




WELCOME SCREEN

Touch anywhere on the screen to start the app setup.



CHOOSE LANGUAGE, TEMPERATURE SCALE AND TIME FORMAT

1. Choose language.
2. Choose °C or °F.
3. Choose 12 or 24 hour clock.
4. Touch **“Next”** button to continue.




REGISTRATION

NOTICE

You must register before logging in. If you have already registered go directly to login. Registration is one time only. Touch the “Register” button.


or

Login and accept the “Terms and Conditions”. Touch “Login” button.



REGISTRATION – TERMS & CONDITIONS

1. Fill in your data.
2. Create a password at least 8 characters in length.
3. Confirm password.
4. Accept the “**Terms and Conditions**”.
5. Touch “**Register**” button.




The screenshot shows a registration form on a tablet. It includes the following elements:

- Phone: [input field]
- E-mail: [input field]
- Password: [input field] with a note "8-character min."
- Confirm Password: [input field]
- A checkbox with the text "To log in you must accept the [Terms and Conditions](#)"
- A red "Back" button at the bottom left.
- A green "Register" button at the bottom right, which is being touched by a finger.


REGISTRATION – TERMS & CONDITIONS

Touch “OK” in pop-up.



REGISTRATION – EMAIL


Touch the link in the confirmation email for verification.



REGISTRATION – VERIFICATION


You will be shown a verification message that you have successfully registered the myfire app.

Touch **“Return to App”**.




LOGIN

1. Auto fill email.
2. Type in password.
3. Accept “**Terms and Conditions**”.
4. Touch “**Login**” Button.



CONNECT SMART DEVICE TO MYFIRE WI-FI BOX

Touch the  icon.



CONNECT MYFIRE WI-FI BOX TO WI-FI ROUTER

Fill in the following data:

- Type in password of your Wi-Fi Router.

Touch **“Connect”** button.



CONNECTING PROCESS

The process of connecting the myfire Wi-Fi Box to your Wi-Fi Router can take a few seconds.

When the connection is established the myfire Wi-Fi Box leaves the Access Point Mode (Hot Spot) and is connected to your Wi-Fi Router.



FIREPLACE SETTINGS

The myfire app allows you to set up an individual name or icon for your fireplace.

If your fireplace is equipped with the optional LED light setup you can adjust and synchronize the RGB color order to meet the specifications and requirements of your installed RGB LED lights.




CONFIRM FIREPLACE SETTINGS

If your fireplace is equipped with fan, light and AUX touch the circle to activate the corresponding function.

 After setting up the myfire Wi-Fi Box and myfire app, the time has to be synchronized in the settings of the myfire app.

When setup is complete, confirm fireplace settings by touching **“Finish”** button.



CONNECTED MYFIRE WI-FI BOXES

A list of all connected myfire Wi-Fi Boxes is now displayed. Touch **“Start APP”** button to finish installation process and app setup.

Icon explanation:

- ✓ Setup complete
- ⬇ Software updates for myfire Wi-Fi Box available
- ▶ Setup incomplete
- ! myfire Wi-Fi Box is not compatible



CONGRATULATIONS

The myfire app is ready to go and the home screen is displayed.



