

# Checklist: disinfecting equipment



Use rubber gloves and disinfect your hands with alcohol.



Blow/brush the surfaces of your equipment clean of any debris.



Dilute a clean microfiber or lintfree wipe in (70-99,9%) isopropyl alcohol.

⚠ Never spray any liquid solution directly onto the lens or equipment for the risk of droplets penetrating the barrel and contaminating internal surfaces.



Wipe all surfaces until they are thoroughly cleaned.



Dab a new lens towel in 99.9% isopropanol alcohol and wipe the surface clean in a circular motion from the center to the edge of the optical element.



Denatured alcohol (ethanol) is **NOT** recommended for cleaning equipment.

Used microfiber wipes should be washed regularly.



Use 99.9% isopropyl alcohol for fast evaporation and minimal streaking.



Let all surfaces dry.

