



SHOWER HARDWARE CARE INSTRUCTIONS

Morse Industries shower enclosures will provide beauty and function for years.

To prolong the life of your shower, please follow some simple guidance and maintenance instructions.

HARDWARE CARE

Proper care of the shower hardware will result in a long life. Neglecting to take proper maintenance steps will result in premature failure or deterioration.

Wipe down the hardware after each use.

This simple action will minimize the chances that any harmful mineral deposits will damage the beautiful finish of the hardware. If mineral deposits do occur, a soapy solution must be used for removal

A weekly cleaning can be an acceptable substitution when it is not possible to cleanse after each use.

1. Use mild soap mixed with warm water.
Suggested use consists of a couple drops of mild soap into warm water.
2. Apply the soapy mixture to the hardware using a non-abrasive cloth.
3. Rinse thoroughly with warm water, dry when done.

Do not use an abrasive cleaner/cleanser or solvents such as acetone or denatured alcohol. This will cause irreversible damage to the lacquer coverings of the components. Avoid all harsh solvents, chemicals and scrubbing tools.

GLASS CARE

Care should be taken to ensure the longevity and beauty of the glass. Just like with hardware, if cleaning and maintenance are neglected, unpleasant results will occur.

After each shower use, remove water from glass with a squeegee or similar device.

Daily use is strongly encouraged. The practice of cleaning the glass daily will result in less cleaning required in the long run.

Morse Industries recommends the use of a liquid surface protector on the glass. This will help keep water from beading up and evaporating on the glass. Use this in conjunction with the daily squeegee cleaning.

The adherence to these guidelines will result in the lasting beauty of your high-quality shower hardware and glass. If you need additional information, contact the installer of the shower.

This is a good source for information and cleaning products.

For additional support call 800.325.7513 or visit our website www.morseindustries.com



Northwest Distribution Facility
Morse Industries Headquarters
25811 74th Avenue South
Kent, WA 98032

Southwest Distribution Facility
Morse Industries
3080 Enterprise Avenue, Suite A
Brea, CA 92821

Central U.S. Distribution Facility
Morse Industries
4041 N. Santa Fe Ave.
Oklahoma City, OK 73118

Mid-Atlantic Distribution Facility
Morse Industries
1630 Old Dunbar Road
West Columbia, SC 29172