



**LEGEND**

- CONDUCTORS CONNECTED
- CONDUCTORS NOT CONNECTED
- CONDUCTOR INDICATING LOAD DIRECTION
- CURRENT TRANSFORMER

- Only qualified electrical personnel should install this equipment.
- Before performing installation or maintenance, disconnect all sources of electric power.
- Use appropriate personal protective equipment (PPE) and follow safe electrical work practices.

Find diagrams for more configurations at [wattwatchers.com.au/support](http://wattwatchers.com.au/support)

- Installation Notes:**
- 1) Auditor is DIN-rail mounted and requires 35mm wide space.
  - 2) Current transformer installation –  
For grid monitoring, K is towards grid, arrow is towards load.  
For load monitoring, K is towards grid, arrow is towards load.
  - 3) Current transformers must be suitably secured in position.
  - 4) All wiring shall be tidy and secured in accordance with the wiring rules in your jurisdiction.
  - 5) An existing or new protective device can be used depending on the regulations in your jurisdiction.
  - 6) Follow the rules in your jurisdiction for the use of RCD protection.
  - 7) For more information, refer to the quick start guide and [wattwatchers.com.au/support](http://wattwatchers.com.au/support)

Place current transformer connected to...	On cables connected to...
Terminals 1+ and 4+	A-Phase
Terminals 2+ and 5+	B-Phase
Terminals 3+ and 6+	C-Phase

Issue	Description	Drawn	Approved	Date
1	Final			03/19



T 2 9 WATTWAT  
A T V A T T T T A W  
I T A T M T A W T T A B A T  
A T A W T T W T T W  
A T A W M V W T T T W T T

Client Details

Drawn By: KS  
Date: 03/19  
Approved By: JC  
Date: 03/19

Project title: CONNECTION DIAGRAMS

Drawing title: A6M MONITORING 3-PHASE MAINS + 1-PHASE LOAD CONNECTION DIAGRAM

Project Code: 20180153  
Drawing No: WW018031  
Status: FINAL  
Revision: A  
Scale: NTS