



- Installation Notes:**
- 1) Auditor is DIN-rail mounted and requires 35mm wide space.
 - 2) Current transformer installation – For load monitoring, K is towards the grid, arrow is towards the load.
 - 3) Current transformers must be suitably secured in position.
 - 4) All wiring shall be tidy and secured in accordance with the wiring rules in your jurisdiction.
 - 5) An existing or new protective device can be used depending on the regulations in your jurisdiction.
 - 6) Follow the rules in your jurisdiction for the use of RCD protection.
 - 7) Wattwatchers recommends the placement of monitoring CT's on the circuits being switched, but this is not mandatory.
 - 8) For more information, refer to the quick start guide and wattwatchers.com.au/support

Find diagrams for more configurations at wattwatchers.com.au/support

Issue	Description	Drawn	Approved	Date
1	Final			03/19
2				
3				
4				
5				



T 2 9 WATTWAT
 A M A T V A T T T T A W
 I T A T M T A W T T A W
 A T A W M T W T T W T T
 WATTWAT

Client Details

Drawn By: KS
 Date: 03/19
 Approved By: JC
 Date: 03/19

Project title: CONNECTION DIAGRAMS

Drawing title: A6W+3SW MONITORING SIX 1-PHASE LOADS + 1-PHASE LOAD SWITCHING

Project Code: 20180153	Status: FINAL	Revision: A
Drawing No: WW018038	Scale: NTS	